

The following are a list of Phones that can do contacts back up

**KEY**

- Auto Settings: We will send you a text with the settings to make it easier for you
- Manual Settings: We will provide you instructions on how to set up your phone

| Manufacturer | Model                | Backup of Contacts |
|--------------|----------------------|--------------------|
| LG           | Chocolate 2 (BL20)   | Auto Settings      |
| LG           | KC910                | Auto Settings      |
| LG           | KF700                | Auto Settings      |
| LG           | KT520                | Auto Settings      |
| LG           | New Chocolate (BL40) | Auto Settings      |
| LG           | VIEWTY KU990         | Auto Settings      |
| MOTOROLA     | E1 ROKR              | Auto Settings      |
| MOTOROLA     | L6                   | Auto Settings      |
| MOTOROLA     | L7                   | Manual Settings    |
| MOTOROLA     | U6 PEBL              | Auto Settings      |
| MOTOROLA     | V3                   | Auto Settings      |
| MOTOROLA     | V360                 | Manual Settings    |
| MOTOROLA     | V3i                  | Auto Settings      |
| MOTOROLA     | V3x                  | Manual Settings    |
| MOTOROLA     | V545                 | Manual Settings    |
| MOTOROLA     | V547                 | Manual Settings    |
| MOTOROLA     | V547                 | Manual Settings    |
| MOTOROLA     | V600                 | Manual Settings    |
| MOTOROLA     | V620                 | Manual Settings    |
| MOTOROLA     | Z3                   | Auto Settings      |
| MOTOROLA     | ZN5                  | Auto Settings      |
| NOKIA        | 3109                 | Manual Settings    |
| NOKIA        | 5000                 | Manual Settings    |
| NOKIA        | 5070                 | Manual Settings    |
| NOKIA        | 5200                 | Manual Settings    |
| NOKIA        | 5300                 | Manual Settings    |
| NOKIA        | 6020                 | Manual Settings    |
| NOKIA        | 6021                 | Manual Settings    |
| NOKIA        | 6070                 | Manual Settings    |
| NOKIA        | 6080                 | Manual Settings    |
| NOKIA        | 6101                 | Manual Settings    |
| NOKIA        | 6111                 | Manual Settings    |
| NOKIA        | 6131                 | Manual Settings    |
| NOKIA        | 6230                 | Auto Settings      |
| NOKIA        | 6233                 | Manual Settings    |
| NOKIA        | 6280                 | Manual Settings    |
| NOKIA        | 6300                 | Manual Settings    |

| Manufacturer | Model            | Backup of Contacts |
|--------------|------------------|--------------------|
| NOKIA        | 6600             | Auto Settings      |
| NOKIA        | 6630             | Auto Settings      |
| NOKIA        | 6680             | Auto Settings      |
| NOKIA        | 6820             | Manual Settings    |
| NOKIA        | 6822             | Manual Settings    |
| NOKIA        | 7260             | Manual Settings    |
| NOKIA        | 7373             | Manual Settings    |
| NOKIA        | 7610             | Auto Settings      |
| NOKIA        | 2323 Classic     | Manual Settings    |
| NOKIA        | 2330 Classic     | Manual Settings    |
| NOKIA        | 5310 XpressMusic | Manual Settings    |
| NOKIA        | 5140i            | Manual Settings    |
| NOKIA        | 5220 XpressMusic | Manual Settings    |
| NOKIA        | 5500D            | Auto Settings      |
| NOKIA        | 5800 XpressMusic | Auto Settings      |
| NOKIA        | 6212 Classic     | Manual Settings    |
| NOKIA        | 6220 Classic     | Auto Settings      |
| NOKIA        | 6230i            | Manual Settings    |
| NOKIA        | 6303 Classic     | Manual Settings    |
| NOKIA        | 6500 Classic     | Manual Settings    |
| NOKIA        | 6500 Slide       | Manual Settings    |
| NOKIA        | 6600 Fold        | Manual Settings    |
| NOKIA        | 6600 Slide       | Manual Settings    |
| NOKIA        | 6600i Slide      | Manual Settings    |
| NOKIA        | 6610i            | Manual Settings    |
| NOKIA        | 6700 Classic     | Manual Settings    |
| NOKIA        | 7100 Supernova   | Manual Settings    |
| NOKIA        | 7250i            | Manual Settings    |
| NOKIA        | 7610 Supernova   | Manual Settings    |
| NOKIA        | 8800D            | Manual Settings    |
| NOKIA        | E50              | Auto Settings      |
| NOKIA        | E52              | Auto Settings      |
| NOKIA        | E65              | Auto Settings      |
| NOKIA        | E71              | Manual Settings    |
| NOKIA        | N70              | Auto Settings      |
| NOKIA        | N73              | Auto Settings      |
| NOKIA        | N78              | Auto Settings      |
| NOKIA        | N80              | Auto Settings      |
| NOKIA        | N81 8GB          | Auto Settings      |
| NOKIA        | N82              | Auto Settings      |
| NOKIA        | N86 8MP          | Auto Settings      |
| NOKIA        | N91              | Auto Settings      |

| Manufacturer  | Model               | Backup of Contacts |
|---------------|---------------------|--------------------|
| NOKIA         | N95                 | Auto Settings      |
| NOKIA         | N95 8GB             | Auto Settings      |
| NOKIA         | N96                 | Auto Settings      |
| NOKIA         | X3                  | Manual Settings    |
| NOKIA         | X6                  | Auto Settings      |
| NOKIA         | 6700 Slide          | Auto Settings      |
| NOKIA         | 7230                | Manual Settings    |
| NOKIA         | 2220 Slide          | Manual Settings    |
| NOKIA         | 2730 Classic        | Manual Settings    |
| NOKIA         | 6303i               | Manual Settings    |
| NOKIA         | C3                  | Manual Settings    |
| SAMSUNG       | Beat DJ (M7600)     | Auto Settings      |
| SAMSUNG       | F480i               | Manual Settings    |
| SAMSUNG       | Lucido              | Auto Settings      |
| SAMSUNG       | M8800 Pixon         | Manual Setting     |
| SAMSUNG       | Tocco Ultra Touch   | Auto Settings      |
| SAMSUNG       | Genio Touch (S3650) | Auto Settings      |
| SAMSUNG       | Wave (S8500)        | Manual Settings    |
| SONY ERICSSON | C702                | Auto Settings      |
| SONY ERICSSON | C902                | Auto Settings      |
| SONY ERICSSON | C903                | Auto Settings      |
| SONY ERICSSON | C905                | Auto Settings      |
| SONY ERICSSON | Jalou (F100i)       | Auto Settings      |
| SONY ERICSSON | K300i               | Auto Settings      |
| SONY ERICSSON | K310i               | Auto Settings      |
| SONY ERICSSON | K550i               | Auto Settings      |
| SONY ERICSSON | K610i               | Auto Settings      |
| SONY ERICSSON | K610im              | Auto Settings      |
| SONY ERICSSON | K700i               | Auto Settings      |
| SONY ERICSSON | K750i               | Auto Settings      |
| SONY ERICSSON | K800i               | Auto Settings      |
| SONY ERICSSON | K810i               | Auto Settings      |
| SONY ERICSSON | K850i               | Auto Settings      |
| SONY ERICSSON | Naite (J105i)       | Auto Settings      |
| SONY ERICSSON | S500i               | Auto Settings      |
| SONY ERICSSON | T610                | Auto Settings      |
| SONY ERICSSON | T630                | Auto Settings      |
| SONY ERICSSON | T700                | Auto Settings      |
| SONY ERICSSON | W200i               | Auto Settings      |
| SONY ERICSSON | W300i               | Auto Settings      |
| SONY ERICSSON | W350i               | Auto Settings      |
| SONY ERICSSON | W550i               | Auto Settings      |

| Manufacturer  | Model | Backup of Contacts |
|---------------|-------|--------------------|
| SONY ERICSSON | W580i | Auto Settings      |
| SONY ERICSSON | W595  | Auto Settings      |